



DeWalt DC970 Battery Replacement

This guide will show you how to properly remove the battery for this device.

Written By: jake



INTRODUCTION

For this device, removing the battery is very easy and with the help of this guide you will be able to remove your battery in no time.

Step 1 — Battery



- Compress the buttons on either side of the battery and lift the drill away from battery.

Step 2



- Remove battery from drill.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-15 04:05:21 AM.